

Press 'P' on the 'stat. You will see a number flashing on top of the display. This is the 'DAY' number. At this point you select which system you want to use. Either 24 Hr. (each day the same), or 5/2 day then press either of the keys showing a triangle on it. As you press the key, you may get all the days of the week showing, or a five day two day display. When you have selected your 7day, or 5 day 2 day, press 'P' again.

You are now going to select your programme. There are 9 programmes in the thermostat. Programmes 1 - 6 are pre-set in the factory and cannot be altered, except for temperatures. Please refer to your instruction manual where it shows PROGRAM NUMBER & PROGRAM PROFILE.

The numbers along the bottom of the program profile, represent the 24 hours in the day.

The blacked out portion above the numbers indicates when the thermostat is in 'Comfort' mode and the clear spaces indicate 'Economy mode.

Having set the day number/numbers, press 'P' , and a 'P' number will flash at the bottom of the display. Again using the buttons with the triangles step through to the pre-set programmes to select one of these if they are suitable for your requirements.

If you want to put in your own programme, keep pressing the triangle button until you reach programme 7, 8, or 9. Press 'P' again. The display should now show, the day/days number the number '0' and your programme number, plus a sun or moon sign and a flashing cursor in the bottom left hand corner of the display. The 0 equals the time between midnight and one o'clock, 1 equals the time between one and two o'clock etc.

Using the button with the upward pointing triangle, press it until the cursor arrives at the hour you would like you heating to come on. Say 6 'clock. Next, press the button showing the SUN/MOON sign. Each press of this button gives an hour of heating at the COMFORT temperature, so pressing it 3 times will give you heating from 6am until 9am Pressing the up triangle button will then move the time forward again to say 5 o'clock. Again pressing the SUN/MOON button 4 times will give you a further 4 hours of heating at the COMFORT SETTING, and thus you set your heating ON times. Pressing the 'SUN/MOON' button will place down a black box down if there isn't one there, or will remove one if there is.

N.B. When using the 5/2 day option, the 5 day settings have to be made on programme 7,8 or 9, then the 2 day settings have to be made on one of the remaining two programmes.

Next press the button with the clock symbol, the day number will flash and the time will be displayed. Using either of the triangle buttons, set the current day of the week. Monday = day 1, Tuesday = day 2 etc. Press the clock symbol again, the HOURS will flash. Set this using either of the triangle buttons. When the hours have been set, press the clock symbol again and the minutes will flash. Again using either triangle buttons, set the minutes. When you have done this, press the clock symbol to exit the time setting.

Press the button showing the 'THERMOMETER' (right hand side of the 'P' button) If a crescent moon symbol appears, press the SUN/MOON button until a SUN symbol appears. This is your COMFORT temperature, the temperature you want to sit in and relax. Again use the triangle buttons to set this temperature to say 20°C

Press the SUN/MOON button again, a crescent moon appears, this is the ECONOMY temperature setting. This is the temperature you don't want your house to fall below. Use the triangle buttons to set this temperature, typically around 15deg C, but you choose your own temperature settings.

If you find your room is too warm and you're in COMFORT mode, press the SUN/MOON button, this will toggle from COMFORT to ECONOMY and switch your heating off. Obviously if you are too cold in an ECONOMY setting, toggle it to the COMFORT setting.

If too cold in a COMFORT setting, use the thermometer button to raise the temperature to something a little higher. (Remember the SUN symbol must be showing when raising the COMFORT temperature)